

# Information Technology Essentials

## COMP106



*Instructor :*

*Asaad Alhijaj*

### **Chapter 6**

## **Maintaining and Troubleshooting Peripheral Components**



## Objectives

- ◆ In this session, you will learn to:
  - ◆ Test and troubleshoot display devices.
  - ◆ Maintain and troubleshoot input devices.
  - ◆ Test and troubleshoot adapter cards.
  - ◆ Troubleshoot multimedia devices.
  - ◆ Troubleshoot storage devices.

## Troubleshoot Display Devices

- ◆ Following are the common display device issues:
  - ◆ Monitor is dark or power indicator light is not lit.
  - ◆ No image displayed on the monitor.
  - ◆ Monitor flickers or is distorted.
  - ◆ Monitor turns itself off.
  - ◆ Screen goes blank, flickers, or acts bizarrely when a specific application is active.
  - ◆ Monitor is on, but display is all white.
  - ◆ Monitor crackles or whines.
  - ◆ Physical damage, internal or external.

## Activity 6-1

### Activity on Troubleshooting Display Devices



## Maintain and Troubleshoot Input Devices

- ◆ Before maintaining and troubleshooting input devices, you need to understand the following:
  - ◆ Common input device issues
  - ◆ Input device maintenance techniques

## Common Input Device Issues

- ◆ Following are the keyboard issues:
  - ◆ Keys stick.
  - ◆ User with physical limitations is currently unable to use the standard keyboard.
  - ◆ No input is sent when keys are pressed.
  - ◆ Keyboard-related message or beep codes given during computer boot.
  - ◆ Wrong characters are displayed on the screen when user inputs information.
  - ◆ Multimedia buttons not working properly.
  - ◆ New keyboard won't plug into the same port as the old keyboard.

## Common Input Device Issues (Contd..)

- ◆ Following are the pointing device issues:
  - ◆ Mouse pointer jumps around on the screen.
  - ◆ Mouse works sometimes, but not others.
  - ◆ Mouse is not working.
  - ◆ USB mouse is not working properly.

## Input Device Maintenance Techniques

- ◆ Following are the various techniques for input device maintenance:
  - ◆ Occasionally disconnect keyboards and mice and gently wipe them clean.
  - ◆ Clean loose debris from inside a trackball or mouse.
  - ◆ Gently shake an upside-down keyboard to remove debris.
  - ◆ Provide a clean, flat mouse pad or other mousing surface.
  - ◆ To avoid spills that can damage input devices, keep food and liquids away from computer systems.
  - ◆ Replace cordless device batteries regularly.



## Activity 6-2

### Activity on Maintaining And Troubleshooting Input Devices

## Troubleshoot Adapter Cards

- ◆ Following are the common adapter card issues:
  - ◆ Adapter seems to work fine until you replace the system case.
  - ◆ Card works fine in another slot, but not in particular slot.
  - ◆ Card tests fine and slot tests fine, but services are unavailable.
  - ◆ Services provided by the adapter or a device connected to the adapter work intermittently.

## Activity 6-3

### Activity on Troubleshooting Adapter Cards

## Troubleshoot Multimedia Devices

- ◆ Following common multimedia device issues:
  - ◆ No sound when speakers worked fine before.
  - ◆ No sound when speakers never worked.
  - ◆ Microphone won't work.

## Activity 6-4

### Activity on Troubleshooting Multimedia Devices



## Troubleshoot Storage Devices

- ◆ Before troubleshooting storage devices, you need to understand the following:
  - ◆ Common storage device issues
  - ◆ Parallel ATA drive troubleshooting tips
  - ◆ SCSI drive troubleshooting tips

## Common Storage Device Issues

- ◆ Following are the hard disk drives issues:
  - ◆ Error message at booting time.
  - ◆ POST error codes.
  - ◆ Can't read from or write to the drive.
  - ◆ Drive is making grinding noises.
  - ◆ Data is frequently being corrupted.
  - ◆ Utilities are not running properly.
  - ◆ Hard drive is slow.

## Common Storage Device Issues (Contd.)

- ◆ Following are the optical drives issues:
  - ◆ Can't insert or remove disk.
  - ◆ Disk tray stuck.
  - ◆ Cannot read disk.
  - ◆ No sound.
  - ◆ Intermittent problems.
  - ◆ Can't view DVD movies.
- ◆ Following are the floppy disks and tape drives issues:
  - ◆ Read/write problems.
  - ◆ Unable to insert a floppy into an internal tape drive.
  - ◆ Unable to insert a tape into an internal tape drive.

## Parallel ATA Drive Troubleshooting Tips

- ◆ Following are the tips for troubleshooting PATA drive:
  - ◆ For one drive on a channel, configure as Single or Cable Select.
  - ◆ For two drives per channel, configure as Master and Slave, or Cable Select.
  - ◆ When removing a drive, configure remaining drive as Single.
  - ◆ Use compatible drive modes.

## Parallel ATA Drive Troubleshooting Tips (Contd..)

- ◆ Following are the tips for troubleshooting SATA drive:
  - ◆ Make sure controller card is supported.
  - ◆ Make sure controller driver is latest version.
  - ◆ Install driver manually if not detected.
  - ◆ Load controller to bypass drive size limitation.
  - ◆ Use jumpers to limit transfer rate if drive transfer rate higher than controller rate.



## SCSI Drive Troubleshooting Tips

- ◆ Following are the tips for troubleshooting SCSI drive:
  - ◆ Always check IDs and termination.
  - ◆ Handle SCSI cable carefully.
  - ◆ For a bootable SCSI disk, enable the SCSI BIOS.
  - ◆ Use proper cables.
  - ◆ Use proper connectors.

## Activity 7-1

### Activity on Troubleshooting Hard Drive Problems

## Activity 7-3

### Activity on Troubleshooting Optical Drive Problems

## Summary

- ◆ In this session, you learned that:
  - ◆ Following are the common adapter card issues:
    - ◆ Card won't work in one slot.
    - ◆ Card and slot test fine, but services unavailable.
  - ◆ Following are the common display device issues:
    - ◆ Power issue.
    - ◆ Connection or settings issue.
    - ◆ Driver, magnetism, or interference issue.
    - ◆ Color quality or resolution issue.
  - ◆ Following are the input device maintenance techniques:
    - ◆ Clean loose debris from inside a trackball or mouse.
    - ◆ Gently shake an upside-down keyboard to remove debris.

## Summary (Contd.)

- ◆ Following are the common multimedia device issues:
  - ◆ No sound when speakers worked fine before.
  - ◆ No sound when speakers never worked.
  - ◆ Microphone won't work.
- ◆ Following are the common storage device issues:
  - ◆ Boot problems in hard disk drive.
  - ◆ Disk tray stuck in optical drives.
  - ◆ Read/write problems in floppy and tape disk drive
- ◆ Following are the parallel ATA drive troubleshooting tips:
  - ◆ When removing a drive, configure remaining drive as Single.
  - ◆ Use compatible drive modes.
  - ◆ Install driver manually if not detected
- ◆ Following are the SCSI drive troubleshooting tips:
  - ◆ Check IDs and termination.
  - ◆ Handle SCSI cable carefully.